


# HelMoRo

**Assembly Instructions** 


23.06.2023



# **Assembly Sequence**


### 1. Wheels + Motors

4x Wheels and Motors




# 2. Chassis

- Jetson with Fan
- 2x Motor Controller
- Battery Protection
- DC/DC Converter
- Voltmeter
- Power Switch



# 3. Bodywork

- Hull
- Camera
- Lidar
- Battery Holder
- Optional: Wheel Caps, iPad Holder and Fork




# 1. Wheels and Motors

# Overview



**Frame Mount** 



Wheels and Motors mounted on Frame Mount

# List of machined or supplied parts

- 1x HEL-04-01000-02 / Frame Mount
- 4x HEL-04-01001-00 / Motor FIT 0186
- 4x HEL-06-01002-00 / Wheel Adapter
- 4x HEL-06-01000-00 / Wheel


Wheel

# **List of normed parts (screw, pins, etc.)**

- 40x DIN 7984 M3 x 8 --- 6.5N / Screw M3x8
- 4x DIN 7984 M3 x 12 --- 10.5N / Screw M3x12


# 1. Wheels and Motors

# **Details**




**Motor into Frame Mount** 

- (1x Frame Mount)
- 1x Motor FIT 0186
- 6x Screw M3x8



**Add Wheel Adapter** 

- 1x Wheel Adapter
- 1x Screw M3x12



**Add Wheel** 

- 1x Wheel
- 4x Screw M3x8

### List of machined or supplied parts

- 1x HEL-04-01000-02 / Frame Mount
- 4x HEL-04-01001-00 / Motor FIT 0186
- 4x HEL-06-01002-00 / Wheel Adapter
- 4x HEL-06-01000-00 / Wheel


# List of normed parts (screw, pins, etc.)

- 40x DIN 7984 M3 x 8 --- 6.5N / Screw M3x8
- 4x DIN 7984 M3 x 12 --- 10.5N / Screw M3x12

**4**x

Note: Wheel that can't be inserted from the side has to be inserted first.

# 2.1 Motor Controller Plate and IMU



**Top View** 

**Bottom View** 

# 1. Mount Motor Controller Plate on Top Plate

- 1x Top Plate
- 1x Motor Controller Plate
- 2x Screw M3x4

- 2x HEL-05-03000-00 / Screw M3x4
  - 4x ISO 4762 M2 x 6 6N / Screw M2x6

List of normed parts (screw, pins, etc.)


List of machined or supplied parts

■ 1x HEL-04-01010-01 / Top Plate

■ 1x HEL-06-03003-00 / IMU


- 4x Washer ISO 7092 2 / Washer M2
- 4x DIN 7984 M3 x 8 --- 6.5N / Screw M3x8

■ 1x HEL-04-01009-01 / Motor Controller Plate



### 2. Add IMU

- 1x IMU
- 4x Screw M2x6
- 4x Washer M2




# 3. Mount Top Plate on **Frame Mount**

4x Screw M3x8

# 2.2 Jetson

Fan Jetson



### 1. Mount Fan on Jetson


- 1x Fan
- 1x Jetson
- 4x Screw M2.5x16
- 4x Nut M2.5

# **List of machined or supplied parts**

- HEL-06-01005-00 / Fan
- HEL-06-01003-00 / Jetson
- HEL-04-03004-00 / Underlay Plate for Jetson

# **List of normed parts (screw, pins, etc.)**

- 4x ISO 14581 M2.5x16x16- / Screw M2.5x16
- 4x ISO 4032 M2.5 D N / Nut M2.5
- 4x DIN 7984 M3 x 8 --- 6.5N / Screw M3x8




Underlay Plate for Jetson

# 2. Mount Jetson on Top Plate

- Underlay Plate for Jetson
- 4x Screw M3x8

# 2.3 Motor Control




### 1. Mount Motor Controller

- 2x Motor Controller Kit
- 8x Screw from Motor Controller Kit
- 1x Holder Motor Controller

# **List of machined or supplied parts**

- 2x HEL-06-01004-00 / Motor Controller Kit
- 8x Screw from Motor Controller Kit
- 1x HEL-04-01017-01 / Holder Motorcontroller
- 2x HEL-06-03005-00 / USB Cable

**List of normed parts (screw, pins, etc.)** 




# 2. Connect Cables

2x USB Cable

Note: Connect cables according to electrical circuit diagram.

# 2.3 DC / DC Wandler



# 1. Battery Protection


- 1x Battery Protection
- 1x Battery Connector
- 1x Battery Cable

# List of machined or supplied parts

- 1x HEL-06-03004-00 / DC/DC Converter
- 1x HEL-06-03001-01 / LED Voltmeter
- 1x HEL-06-03002-00 / Power Switch
- 1x HEL-03-03000-00 / Battery Protection
- 1x Battery Connector (Deans M/F)
- 1x Battery Cable (EP Silicone Cable 0.5mm²/)

List of normed parts (screw, pins, etc.)

Deans M/F




### 2. DC / DC Converter

- 1x DC / DC Converter
- 1x Power Switch
- 1x LED Voltmeter

Note: Solder the connections according to the electrical circuit diagram.

# 2.4 Circuit Board Box



# 1. Battery Protection

1x Circuit Board Holder

# **List of machined or supplied parts**

■ HEL-04-01005-01 / Circuit Board Holder

# List of normed parts (screw, pins, etc.)


3x M3x30 Screw



### 2. DC / DC Converter

3x M3x30 Screw

# 2.5 Voltmeter & Power Switch



### 1. Voltmeter


- 2x Screw M2x5
- 2x Nut M2

# List of machined or supplied parts


# List of normed parts (screw, pins, etc.)

- 2x DIN 7985A M2x5 / Screw M2x5
- 2x ISO 4032 M2 D N / Nut M2






2. Power Switch



### 3. Connect Cables

Note: Connect the cables according to the electrical circuit diagram.

# 3.1 Power Supply Connector & Lidar



# 1. Power Supply Connector

- 1x Hood
- 1x Power Supply Connector

# 2. Lidar Adapter

### 2. Lidar

- 1x Lidar
- 1x Lidar Adapter
- 4x Screw M3x8


# List of machined or supplied parts

- HEL-04-03002-00 / Hood
- HEL-06-03000-00 / Power Supply Connector
- HEL-06-01008-00 / Lidar
- HEL-06-01007-00 / Lidar Adapter

# **List of normed parts (screw, pins, etc.)**

4x M3x8

# 3.2 Camera and Hood on Chassis



1x Camera

1. Camera

- 1x Camera Plate
- 2x Screw M3x12
- 4x Screw M3x8

### List of machined or supplied parts

- HEL-06-01006-00 / Camera
- HEL-04-01013-02 / Camera Plate

### List of normed parts (screw, pins, etc.)

- 4x DIN 7984 M3 x 8 --- 6.5N / M3x8
- 2x DIN 7984 M3 x 12 --- 10.5N / M3x12
- 4x DIN 7984 M3 x 18 / Screw M3x18




# 2. Mount Hood on Chassis

4x Screw M3x18


Note: Connect the cables of the Hood and the Chassis according to the Electrical Circuit Diagram and then mount the Hood on the Chassis.

# 3.3 Battery Holder and Fork Hull



# 1. Battery Holder

- 1x Battery Holder
- 4x Screw M3x8



### 2. Mount Front Part

- Front Part
- 2x Screw M3x30

# List of machined or supplied parts

- HEL-04-01004-00 / Battery Holder
- HEL-04-03003-00 / Front Part

# **List of normed parts (screw, pins, etc.)**

- 4x M3x8
- 2x M3x30



# 1. iPad Holder

- 1x iPad Holder
- 4x Screw M3x36

# 2.

# 2. Wheel Cap

4x Wheel Cap

# 3. Front Part with Fork

# List of machined or supplied parts

- 1x HEL-04-02001-00 / iPad Holder
- 4x HEL-04-03000-01 / Wheel Cap
- 1x HEL-04-03003-00 / Front Part with Fork

# **List of normed parts (screw, pins, etc.)**

- 4x M3x36
- 4x M3x30

# 3. Fork

- 1x Front Part with Fork
- 4x Screw M3x30



# **END**

